

# 10 points to remember about Wet Rooms

1. Shower areas must be tanked to avoid leaking, we recommend our Wet Deck tanking system. A specialised installation service can be offered.
2. Wet Deck trays are suitable for wooden floors only. Concrete floors require a Screed waste fitting.
3. The tray will slope towards the waste. It will not be completely flat.
4. Mosaic tiles are best. Larger tiles can be used but will need cutting diagonally to fit the fall of the tray.
5. Overhead showers like Raindance, Rainmaker & Rainsky are more suited to wetrooms than directional heads which spray more.
6. A Wet Deck tray with a strip waste is recommended for higher capacity, or dual shower heads.
7. Additional hand showers are strongly recommended to clean the shower area.
8. A true wet room has no glass. A glass panel with no door will not keep the water from splashing into the room.
9. Underfloor heating is strongly recommended to help dry out the floor around the shower.
10. Our Wet Deck system is a special and as such is non cancellable and non returnable.